

Marcopolo TATA bus

sl no	spare parts	Qty	Price	Charge
1	Marcopolo TATA Bus Spare parts, Air Filter	No	3500	180
2	Marcopolo TATA Bus Spare parts, Brake Shoe	Set	4500	700
3	Marcopolo TATA Bus Spare parts, Brake Pad	Set	4000	700
4	Marcopolo TATA Bus Spare parts, Hub Bearing F Inner	No	3500	880
5	Marcopolo TATA Bus Spare parts, Hub Bearing F Outer	No	3500	880
6	Marcopolo TATA Bus Spare parts, Hub Oil Seal	No	550	350
7	Marcopolo TATA Bus Spare parts, Tube Oil Seal	No	850	350
8	Marcopolo TATA Bus Spare parts, Brake Disc	No	8000	980
9	Marcopolo TATA Bus Spare parts, Hub Check Nut	No	850	120
10	Marcopolo TATA Bus Spare parts, Check Nut Lock	No	500	120
11	Marcopolo TATA Bus Spare parts, Hub Splender	No	9000	1800
12	Marcopolo TATA Bus Spare parts, Shock Absorber Front	No	3500	550
13	Marcopolo TATA Bus Spare parts, Shock Absorber Rear	No	3600	550
14	Marcopolo TATA Bus Spare parts, Shock Absorber Bush	No	300	120
15	Marcopolo TATA Bus Spare parts, Stablizer Bar Bush Front	No	300	350
16	Marcopolo TATA Bus Spare parts, Stablizer Bar Bush Rear	No	300	320
17	Marcopolo TATA Bus Spare parts, Link Bush Front	No	800	450
18	Marcopolo TATA Bus Spare parts, Link Bush Rear	No	800	450
19	Marcopolo TATA Bus Spare parts, Spring Main Rear	No	2000	1280
20	Marcopolo TATA Bus Spare parts, 2ND	No	1900	1050
21	Marcopolo TATA Bus Spare parts, 3RD	No	1800	820
22	Marcopolo TATA Bus Spare parts, 4TH	No	1700	700
23	Marcopolo TATA Bus Spare parts, 5TH	No	1600	550
24	Marcopolo TATA Bus Spare parts, Spring Main Front	No	1980	920
25	Marcopolo TATA Bus Spare parts, 2ND	No	1980	820
26	Marcopolo TATA Bus Spare parts, 3RD	No	1800	440
27	Marcopolo TATA Bus Spare parts, 4TH	No	1750	350
28	Marcopolo TATA Bus Spare parts, 5TH	No	1550	280
29	Marcopolo TATA Bus Spare parts, Spring Bush Small	No	980	250
30	Marcopolo TATA Bus Spare parts, Spring Bush Big	No	980	280
31	Marcopolo TATA Bus, Spring Bush Big	No	550	120
32	Marcopolo TATA Bus Spare parts, Spring Bush Metal	No	780	650
33	Marcopolo TATA Bus Spare parts, Center Bolt	No	300	320
34	Marcopolo TATA Bus Spare parts, Fuel Filter	No	900	280
35	Marcopolo TATA Bus Spare parts, Oil Filter	No	950	280
36	Marcopolo TATA Bus Spare parts, Oil (Castrol)	Ltr	950	450
37	Marcopolo TATA Bus Spare parts, Oil Mak	Ltr	900	450
38	Marcopolo TATA Bus Spare parts, Oil Rimula	Ltr	900	420
39	Marcopolo TATA Bus Spare parts, Gear Oil Castrol	Ltr	950	420
40	Marcopolo TATA Bus Spare parts, Gear Oil Mak	Ltr	900	420
41	Marcopolo TATA Bus Spare parts, Trasmission Oil	Ltr	900	320
42	Marcopolo TATA Bus Spare parts, Hyudraulic Oil	Ltr	950	600

43	Marcopolo TATA Bus Spare parts, Axle Bearing	No	3200	780
44	Marcopolo TATA Bus Spare parts, Axle Oil Seal Inner	No	3100	400
45	Marcopolo TATA Bus Spare parts, Axle Oil Seal Outer	No	660	400
46	Marcopolo TATA Bus Spare parts, Axle Tube Oil Seal	No	650	780
47	Marcopolo TATA Bus Spare parts,Rear Differential Assy	No	60000	3300
48	Marcopolo TATA Bus Spare parts, Differential Side Bearing	No	3200	1400
49	Marcopolo TATA Bus Spare parts, Tail Inner Bearing	No	2850	2100
50	Marcopolo TATA Bus Spare parts, Tail Outer Bearing	No	2850	2100
51	Marcopolo TATA Bus Spare parts, Tail Oil Seal	No	580	750
52	Marcopolo TATA Bus Spare parts, Crown & Tail Assy	Set	77000	2700
53	Marcopolo TATA Bus Spare parts,Ball Joint Upper	No	1450	1800
54	Marcopolo TATA Bus Spare parts, Ball Joint Lower	No	1450	1800
55	Marcopolo TATA Bus Spare parts, Arm Lower	No	6500	750
56	Marcopolo TATA Bus Spare parts, Arm Upper	No	6500	750
57	Marcopolo TATA Bus Spare parts, Arm Bush Lower	No	6200	480
58	Marcopolo TATA Bus Spare parts, Arm Bush Upper	No	1650	480
59	Marcopolo TATA Bus Spare parts, Brake Hose Front	No	2100	380
60	Marcopolo TATA Bus Spare parts, Brake Hose Rear	No	2050	380
61	Marcopolo TATA BusSpare parts, Back Light	No	1550	480
62	Marcopolo TATA Bus Spare parts, Back Light Bulb	No	20	150
63	Marcopolo TATA Bus Spare parts, Side Light	No	120	160
64	Marcopolo TATA Bus Spare parts, Side Light Bulb	No	20	150
65	Marcopolo TATA Bus Spare parts, Head Light	No	4800	800
66	Marcopolo TATA Bus Spare parts, Head Light Bulb	No	180	250
67	Marcopolo TATA Bus Spare parts, Head Gasket	No	3200	4200
68	Marcopolo TATA Bus Spare parts, Head Gasket Set	Set	4800	3700
69	Marcopolo TATA Bus Spare parts, Water Pump	No	4550	2700
70	Marcopolo TATA Bus Spare parts, Fan Belt	No	2100	450
71	Marcopolo TATA Bus Spare parts, Power Steering Belt	No	1600	450
72	Marcopolo TATA Bus Spare parts, Acc Belt	No	1500	450
73	Marcopolo TATA Bus Spare parts, Steering Damper	No	3020	1700
74	Marcopolo TATA Bus Spare parts, Steering Relay	No	1280	1550
75	Marcopolo TATA Bus Spare parts, Steering Drop Arm	No	4500	1880
76	Marcopolo TATA Bus Spare parts, Steering Relay Kit	No	2580	1880
77	Marcopolo TATA Bus Spare parts, Brake Buckket Kit	No	450	750
78	Marcopolo TATA Bus Spare parts, Wheel Cylinder Assy	No	2300	850
79	Marcopolo TATA Bus Spare parts, Feed Pump	No	4580	450
80	Marcopolo TATA Bus Spare parts, Fuel Supply Pump	No	6800	2200
81	Marcopolo TATA Bus Spare parts, Fuel Totter & Head	Set	8500	2700
82	Marcopolo TATA Bus Spare parts, Delivery Valve	Set	2100	300
83	Marcopolo TATA Bus Spare parts, Oil Supply Pump	Set	6500	1900
84	Marcopolo TATA Bus Spare parts, Valve Oil Seal	Set	450	900
85	Marcopolo TATA Bus Spare parts, Clutch Plate	Set	5500	1880
86	Marcopolo TATA Bus Spare parts, Pressure Plate	No	5600	1560
87	Marcopolo TATA Bus Spare parts, Release Bearing	No	2100	1380
88	Marcopolo TATA Bus Spare parts, Master Cylinder Kit	No	3200	980
89	Marcopolo TATA Bus Spare parts, Master Cylinder	No	4500	980

90	Marcopolo TATA Bus Spare parts, Clutch Cylinder Upper	No	2600	700
91	Marcopolo TATA Bus Spare parts, Clutch Cylinder Lower	No	2100	700
92	Marcopolo TATA Bus Spare parts, Brake Booster	No	21000	3200
93	Marcopolo TATA Bus Spare parts, Cross Bearing	No	2080	450
94	Marcopolo TATA Bus Spare parts, Link	No	680	300
95	Marcopolo TATA Bus Spare parts, C V Joint	No	20000	1700
96	Marcopolo TATA Bus Spare parts, Drive Shaft Assy	No	20000	1700
97	Marcopolo TATA Bus Spare parts,Rear Spring Shackel	No	1850	750
98	Marcopolo TATA Bus Spare parts, Tie Rod End Small	No	850	650
99	Marcopolo TATA Bus Spare parts, Tie Rod End Big	No	880	680
100	Marcopolo TATA Bus Spare parts, Tie Rod End	Set	880	700
101	Marcopolo TATA Bus Spare parts, King Pin Bearing	Set	980	480
102	Marcopolo TATA Bus Spare parts, King Pin Kit	Set	980	580
103	Marcopolo TATA Bus Spare parts, Radiator Cap	Set	680	100
104	Marcopolo TATA Bus Spare parts, Wheel Nuts & Bolts	No	650	750
105	Marcopolo TATA Bus Spare parts, Self Armature	No	3650	1300
106	Marcopolo TATA Bus Spare parts, Self Carbon	No	1880	1450
107	Marcopolo TATA Bus Spare parts, Self Carnon Rocker	No	1250	800
108	Marcopolo TATA Bus Spare parts, Self Plunger	No	1350	550
109	Marcopolo TATA Bus Spare parts, Timing Belt	No	2000	2700
110	Marcopolo TATA Bus Spare parts, Glow Plug	No	850	1300
111	Marcopolo TATA Bus Spare parts, Engine Mounting	No	1850	1750
112	Marcopolo TATA Bus Spare parts, Gear Box Mounting	No	1680	1400
113	Marcopolo TATA Bus Spare parts, Wiper Blade	No	650	220
114	Marcopolo TATA Bus Spare parts, Battery	No	15000	280
115	Marcopolo TATA Bus Spare parts, Brake Oil	Ltr	480	50
116	Marcopolo TATA Bus Spare parts, Power Steering Oil	Ltr	480	60
117	Marcopolo TATA Bus Spare parts, Key Lock Set	Set	3850	1800
118	Marcopolo TATA Bus Spare parts, Parking Cable Rear	No	3300	1300
119	Marcopolo TATA Bus Spare parts, Parking Cable Front	No	2650	1280
120	Marcopolo TATA Bus Spare parts, Accelator Cablel	No	1300	450
121	Marcopolo TATA Bus Spare parts, Km Cable	No	2300	750
122	Marcopolo TATA Bus Spare parts, Rear Axle Corn	No	900	880
123	Marcopolo TATA Bus Spare parts, Spring Pad	No	650	800
124	Marcopolo TATA Bus Spare parts, Piston	Set	1900	2700
125	Marcopolo TATA Bus Spare parts, Piston Ring	Set	1300	2700
126	Marcopolo TATA Bus Spare parts, Linner	Set	3850	4200
127	Marcopolo TATA Bus Spare parts, Intake Valve	Set	680	1400
128	Marcopolo TATA Bus Spare parts, Exhuast Valve	Set	650	1400
129	Marcopolo TATA Bus Spare parts, Vale Guide	Set	580	900
130	Marcopolo TATA Bus Spare parts, Vaive Seat	Set	780	700
131	Marcopolo TATA Bus Spare parts, Connecting Bearing	Set	880	1800
132	Marcopolo TATA Bus Spare parts, Main Bearing	Set	3200	1800
133	Marcopolo TATA Bus Spare parts, Cam Shaft Bearing	Set	2100	2000
134	Marcopolo TATA Bus Spare parts, Thrush Washer	Set	650	450
135	Marcopolo TATA Bus Spare parts, Crank Shaft	No	19500	2200
136	Marcopolo TATA Bus Spare parts, Connecting Rod	No	3100	780

137	Marcopolo TATA Bus Spare parts, Valve Set	Set	4500	880
138	Marcopolo TATA Bus Spare parts, Grease	Kg	400	650
139	Marcopolo TATA Bus Spare parts, Dhoti	Kg	30	
140	Marcopolo TATA Bus Spare parts, Sk Oil	Ltr	60	
141	Marcopolo TATA Bus Spare parts, Water Paper	No	700	
142	Marcopolo TATA Bus Spare parts, 4W Yok And Teeth	Set	9000	2000
143	Marcopolo TATA Bus Spare parts, 2W Yok And Teeth	Set	9000	2000
144	Marcopolo TATA Bus Spare parts, Main Bearing Oil Seal	No	1900	3700
145	Marcopolo TATA Bus Spare parts, U-Bolt	No	810	450
146	Marcopolo TATA Bus Spare parts, Mobil Filter	No	900	350
147	Marcopolo TATA Bus Spare parts, Diesel Filter	No	800	350
148	Marcopolo TATA Bus Spare parts, CV Joint Assembly	No	18800	700
149	Marcopolo TATA Bus Spare parts, Dust Guard	Set	850	880
150	Marcopolo TATA Bus Spare parts, Engine Oil	Ltr	480	350
151	Marcopolo TATA Bus Spare parts, Coolant	Ltr	280	120
152	Marcopolo TATA Bus Spare parts, Distilled Water	Ltr	150	80
153	Marcopolo TATA Bus Spare parts, Bonnet Cable	Set	650	1700
154	Marcopolo TATA Bus Spare parts, Hand Brake Cable	Set	3500	1200
155	Marcopolo TATA Bus Spare parts, Door Rubber	Set	850	900
156	Marcopolo TATA Bus Spare parts, Safe Guard	Set	6700	1800
157	Marcopolo TATA Bus Spare parts, Fog Light	Set	1250	600
158	Marcopolo TATA Bus Spare parts, Horn	No	1250	350
159	Marcopolo TATA Bus Spare parts, Pop. Shaft-Yoke & Teeth	No	3500	1300
160	Marcopolo TATA Bus Spare parts, Fuse	No	20	10
161	Marcopolo TATA Bus Spare parts, Wheel Bearing	No	4000	1180